




beatsstudio wireless™
QUICK START GUIDE

FOLD + FIT



EN Expand and collapse to play and store.

FR Agrandir et réduire pour jouer et entreposer.

ES Expanda y cierre para reproducir y almacenar.

PT Expanda e oculte para reproduzir e armazenar.



EN Slide earcups up and down to adjust fit.

FR Glissez les écouteurs vers le haut ou le bas pour effectuer l'ajustement.

ES Deslice los auriculares hacia arriba y abajo para ajustar a la medida.

PT Deslize os fones de ouvido para cima e para baixo para ajustar.

WIRELESS MODE



- EN** Press power button without cable for Wireless mode.
- FR** Appuyez sur le bouton d'alimentation sans le câble pour le mode sans fil.
- ES** Presione el botón de encendido sin el cable para el modo Inalámbrico.
- PT** Pressione o botão liga/desliga sem o cabo para o modo Sem Fio.



- EN** Press power button to turn off headphone.
- FR** Appuyez sur le bouton d'alimentation pour fermer le casque d'écoute.
- ES** Presione el botón de encendido para apagar el audífono.
- PT** Aperte o botão liga/desliga para desligar o fone de ouvido.

WIRELESS PAIRING





- EN** Press and hold "b" button for 2 seconds for pair device.
- FR** Appuyez sur le bouton "b" et maintenez-le enfoncé pendant 2 secondes pour apparier l'appareil.
- ES** Presione y mantenga presionado el botón "b" por 2 segundos para conectar el dispositivo.
- PT** Pressione e segure o botão "b" durante dois segundos para emparelhar dispositivos.



- EN** Pair with device when Bluetooth® indicator is blinking.
- FR** Appariez avec l'appareil lorsque l'indicateur Bluetooth^{MD} clignote.
- ES** Conectar con el dispositivo cuando el indicador de Bluetooth® esté parpadeando.
- PT** Emparelhe com o dispositivo quando o indicador Bluetooth® estiver piscando.

WIRELESS CONTROLS



Music Controls

- ▷ Play, Lecture, Reproducir, Reproduzir
- || Pause, Pause, Pausa, Pausa
- ▷▷| Next Track, Prochaine Piste, Pista Siguiente, Próxima Faixa
x2
- |◁◁ Previous Track, Piste Précédente, Pista Anterior, Faixa Anterior
x3


Phone Controls

- ☑ Answer, Répondre, Responder, Atender
- ☒ End Call, Fin de l'Appel, Finalizar Llamada, Encerrar Chamada
- ◀+ Volume Up, Augmenter le Volume, Subir Volumen, Aumentar Volume
- ◀- Volume Down, Baisser le Volume, Bajar Volumen, Diminuir Volume

WIRED MODE




- EN** Plug in audio cable to turn on for Wired mode.
- FR** Branchez le câble audio pour mettre en marche par le mode avec fil.
- ES** Conecte el cable de audio para encenderlo el modo de conexión con cable.
- PT** Conectar o cabo de áudio para acionar o modo Com Fio.



- EN** Remove audio cable to turn off.
- FR** Débranchez le câble audio pour éteindre le casque.
- ES** Retire el cable de audio para apagarlo.
- PT** Remover o cabo de áudio para desligar.


REMOTETALK™ CONTROL

iPod®, iPhone® and iPad®



Android™, BlackBerry®, Windows®

*Functionality may vary by device




Music Controls

▷	Play, Lecture, Reproducir, Reproduzir
	Pause, Pause, Pausa, Pausa
▷▷ x2	Skip Forward, Avancer, Saltar hacia Adelante, Avançar
◁◁ x3	Scan Backward, Reculer, Buscar hacia Atrás, Retroceder

Phone Controls


☎	Answer, Répondre, Responder, Atender
☎x	End Call, Fin de l'Appel, Finalizar Llamada, Encerrar Chamada
🗣	Voice Command, Commande Vocale, Orden de Voz, Comando de Voz
🔊+ -	Volume Control, Contrôle du Volume, Control de Volumen, Control de Volume

MUTE



- EN** Press and hold "b" with audio cable plugged in to mute.
- FR** Appuyez sur le bouton "b" et maintenez-le enfoncé avec le câble audio branché pour passer au mode muet.
- ES** Presione y mantenga presionado "b" con el cable conectado para silenciar.
- PT** Pressione e segure "b" com o cabo de áudio conectado ao modo mudo.

ADAPTIVE NOISE CANCELING ONLY



- EN** Press and hold both the "b" and power button without the cable to enable ANC-only mode.
- FR** Appuyez sur les boutons "b" et d'alimentation et maintenez-les enfoncés sans le câble pour activer le mode ANC seulement.
- ES** Presione y mantenga presionado "b" y el botón de encendido sin el cable para habilitar el modo de solo ANC.
- PT** Pressione e segure os botões "b" e liga/desliga sem o cabo para acionar o modo "somente ANC".

BATTERY POWER + CHARGING



- EN** Tap power button to check battery fuel gauge.
- FR** Appuyez sur le bouton de mise en marche pour vérifier les indicateurs de charge des piles.
- ES** Pulse el botón de encendido para verificar el indicador de energía de la batería.
- PT** Toque o botão liga/desliga para verificar o indicador de carga da bateria.



- EN** Charge using the micro USB cable and power supply provided.
- FR** Chargez à l'aide du câble micro USB et le cordon d'alimentation fournis.
- ES** Cargue usando el micro USB y la fuente de alimentación provista.
- PT** Recarregue utilizando o micro cabo USB e a fonte de alimentação fornecida.

NEED MORE INFORMATION?



beatsbydre.com/support



1-800-442-4000
6am to 7pm PST



Product Care
Entretien du Produit
Cuidado del Producto
Cuidados com o Produto



Product Registration
Enregistrement du Produit
Registro del Producto
Registro de Produto



User Guide
Guide de l'Utilisateur
Guía del Usuario
Guia do Usuário



Knowledge Base
Base de Connaissances
Base de Conocimientos
Base de Dados de Conhecimento



Software Updates
Mises à Niveau des Logiciels
Actualizaciones del Software
Atualizações do Produto

"iPod", "iPhone" and "iPad" are trademarks of Apple Inc., registered in the U.S. and other countries. "Android" is a trademark of Google Inc. "Windows" is a registered trademark of Microsoft Corporation in the United States and other countries. Blackberry® is the property of Research In Motion Limited and is registered and/or used in the U.S. and countries around the world. Used under license from Research In Motion Limited.

"iPod", "iPhone" et "iPad" sont des marques de commerce de Apple Inc., enregistrées aux É.-U. et dans d'autres pays. "Android" est une marque de commerce de Google Inc. "Windows" est une marque déposée de Microsoft Corporation aux États-Unis et dans d'autres pays. Blackberry^{MD}, propriété de Research In Motion Limited, est enregistrée et/ou utilisée aux États-Unis et dans d'autres pays à travers le monde. Il est utilisé sous licence de Research In Motion Limited.




"iPod", "iPhone" y "iPad" son marcas comerciales de Apple Inc., registradas en los EE.UU. y otros países. "Android" es una marca comercial de Google Inc. "Windows" es una marca comercial registrada de Microsoft Corporation en Estados Unidos y otros países. Blackberry® es propiedad de Research In Motion Limited y está registrado y/o se utiliza en los EE.UU. y países de todo el mundo. Utilizado bajo licencia de Research In Motion Limited.

"iPod", "iPhone" e "iPad" são marcas registradas da Apple Inc., registradas nos EUA e em outros países. "Android" é uma marca registrada da Google Inc. "Windows" é uma marca registrada da Microsoft Corporation nos Estados Unidos e em outros países. A marca Blackberry® é propriedade da Research In Motion Limited e é registrada e/ou utilizada nos Estados Unidos e em países do mundo inteiro. Uso sob licença da Research In Motion Limited.

© 2013 Beats Electronics LLC



780-00014-01-A

 beatsbydre.com
 facebook.com/beatsbydre
 [@beatsbydre](https://twitter.com/beatsbydre)



beats**MUSIC**

**BEATS MUSIC WILL
FOREVER CHANGE
THE WAY YOU GET
AND DISCOVER MUSIC.**

**BE AMONG THE
FIRST TO CLAIM
YOUR USERNAME
AND EXPERIENCE IT.**

[BEATSMUSIC.COM/CLAIMYOURNAME](https://beatsmusic.com/claimyourname)

778-00017-00-A

ENGLISH



IMPORTANT SAFETY INFORMATION

Use Responsibly

Do not use headphones when it is unsafe to do so: while operating a vehicle, crossing the street, or during any activity or in an environment where your full attention to your surroundings is required.

It's dangerous to drive while wearing headphones, and in many places, illegal because it decreases your chances of hearing life-saving sounds outside of your vehicle, such as another car's horn and emergency vehicle sirens. Please avoid wearing our headphones while driving. Use an FM transmitter to listen to your mobile media devices instead.

Listen Responsibly

To avoid hearing damage, make sure that the volume on your music player is turned down before connecting your headphones. After placing the headphones in/on your ear, gradually turn up the volume until you reach a comfortable listening level. Noise levels are measured in decibels (dB); exposure to any noise at or above 85 dB can cause gradual hearing loss. Monitor your use; hearing loss is a function of loudness versus time. The louder it is, the less time you can be exposed to it. The softer it is, the more time you can listen to it.



ENGLISH

This decibel (dB) table compares some common sounds and shows how they rank in potential harm to hearing.

SOUND	NOISE LEVEL (dB)	EFFECT
Whisper	30	Very quiet
Quiet Office	50-60	Comfortable hearing levels are under 60 dB
Vacuum Cleaner, Hair Dryer	70	Intrusive; interferes with telephone conversations
Food Blender	85-90	85 dB is the level at which hearing damage (8 hr) begins
Dustbin Lorry, Cement Mixer	100	No more than 15 minutes of unprotected exposure recommended for sounds between 90-100 dB
Power Saw, Drill/Jackhammer	110	Regular exposure to sound over 100 dB of more than 1 minute risks permanent hearing loss
Rock Concert (varies)	110-140	Threshold of pain begins around 125 dB

*Chart information from http://www.nidcd.nih.gov/health/education/teachers/pages/common_sounds.aspx

ENGLISH



FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FEDERAL COMMUNICATION COMMISSION RADIATION EXPOSURE STATEMENT

This EUT is in compliance with SAR for general population/uncontrolled exposure limits in ANSI/IEEE C95.1-1999 and has been tested in accordance with the measurement methods and procedures specified in OET Bulletin 65 Supplement C.

FCC CAUTION

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

ENGLISH

FCC RADIATION EXPOSURE STATEMENT

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

CAUTION

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

CANADA STATEMENT

This device complies with Industry Canada RSS-210. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

DECLARATION OF CONFORMITY STATEMENT

Beats Electronics, LLC hereby declares that this product complies with the essential requirements and other relevant provisions of the guidelines. The Declaration of Conformity can be found on the website www.beatsbydre.com/compliance.

ENGLISH

LIMITED WARRANTY

Your Beats® product is warranted against defects in materials and workmanship for a period of one* ** (1) year from the date of original retail purchase from an authorized Beats® dealer. If a defect exists, Beats® at its option will (1) repair the product at no charge using new or refurbished parts, (2) exchange the product with a functional equivalent product that is new or refurbished, or (3) refund the original purchase price. This does not mean you can abuse your headphones and expect warranty service. We do not cover normal wear and tear, blown speakers, cut cords, bent jacks, scratches, loss or theft. This warranty excludes damages resulting from abuse, accident, modifications or other causes that are not defects in materials and workmanship. Customization of your product will void your warranty.

Any recovery is limited to the original purchase price. No other person is authorized to modify this limited warranty. Your seller is responsible for any other warranties.

This warranty gives you specific legal rights, and you may have other rights that vary by state and jurisdiction. These rights shall not be affected by this limited warranty. This warranty cannot be transferred or assigned.

To obtain warranty service, contact Beats® using the information provided at www.beatsbydre.com/support. **U.S. Residents Only** may call our Toll-Free Number (800) 442-4000. Proof of purchase is required to verify eligibility.

****FOR EUROPE RESIDENTS:** Your Beats Limited Warranty is valid for a period of two (2) years from the date of original retail purchase from an authorized Beats® dealer.

***FOR SWEDEN RESIDENTS:** Your Beats Limited Warranty is valid for a period of three (3) years from the date of original retail purchase from an authorized Beats® dealer.

©2013 Beats Electronics LLC

772-00008-00-A